

# Headlight Restoration - DIY HRK05

## Product Information

### Description

Headlight Restoration Kit - DIY Pack  
for Mild Damage

### Additional Information

Kit Contents: 2 x Yellow-X sachets 2  
x UV Clear Coat sachets 1 x  
protective glove 2 x drying cloths



## Additional Specifications

### Pack Quantity

1

## Installation & Application Information

---



### Yellow-X Cleaning Instructions

- Using the Yellow-X applicator, clean the surface of the headlight by rubbing vigorously to ensure all dirt and grime is removed.
- Wash off the Yellow-X with water.
- Thoroughly dry the lens with one of the supplied white cloths.
- It is imperative that the surface is completely dry before moving on to the next step.

### UV Clear Coat Instructions

- Wear the supplied protective glove to prevent the UV Clear Coat making contact with your skin.
- Using the UV Clear Coat applicator, start at the top of the lens and work your way down, wiping from one side to the other.
- Apply a generous amount of UV Clear Coat as the lines from wiping will self-level.
- Allow at least 1 hour drying time in warmer conditions and even longer in cooler conditions.
- UV Clear Coat may be cleaned off surrounding surfaces using rubbing alcohol.