

Headlight Restoration - DIY HRK05

Product Information

Description

Headlight Restoration Kit - DIY Pack
for Mild Damage

Additional Information

Kit Contents: 2 x Yellow-X sachets 2
x UV Clear Coat sachets 1 x
protective glove 2 x drying cloths



Additional Specifications

Pack Quantity

1

Installation & Application Information



Yellow-X Cleaning Instructions

- Using the Yellow-X applicator, clean the surface of the headlight by rubbing vigorously to ensure all dirt and grime is removed.
- Wash off the Yellow-X with water.
- Thoroughly dry the lens with one of the supplied white cloths.
- It is imperative that the surface is completely dry before moving on to the next step.

UV Clear Coat Instructions

- Wear the supplied protective glove to prevent the UV Clear Coat making contact with your skin.
- Using the UV Clear Coat applicator, start at the top of the lens and work your way down, wiping from one side to the other.
- Apply a generous amount of UV Clear Coat as the lines from wiping will self-level.
- Allow at least 1 hour drying time in warmer conditions and even longer in cooler conditions.
- UV Clear Coat may be cleaned off surrounding surfaces using rubbing alcohol.